

IPC - Designbeläge	Bostik	Mapei	Forbo Eurocol	Schönox	Sika	Thomsit
IPC - Achat Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Achat 2 Designbelag	Stix A 540; A 550	in Prüfung	Eurostar 643/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Granat Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Opal XL Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Opal XS Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Opal Chevron Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Onyx Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - PreisWertKlasse 30 Designbelag	Stix; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - PreisWertKlasse 55 Designbelag	Stix; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Projekt Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Rubin XS Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Rubin XL Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Saphir Plus Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Smaragd Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
IPC - Terra Designbelag 100% PVC frei	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	nicht geprüft	nicht geprüft	K 190 F; K188 S; K195
IPC - Topas XXL Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195
Riviera Maison Designbelag	Stix A 540; A 550	Eco 4 LVT + V4 SP + V4 Evolution	Eurostar 643/644/628/120	Durocoll EC 1 Plus	Sikabond-130	K 190 F; K188 S; K195

IPC - Designbeläge	Wakol	Uzin	Stauf in Prüfung	Wulff
IPC - Achat Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - Achat 2 Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong
IPC - Granat Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - Opal XL Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - Opal XS+CH Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - Opal Chevron Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - Onyx Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - PreisWertKlasse 30 Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - PreisWertKlasse 55 Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - Projekt Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - Rubin XL Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - Rubin XS Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - Saphir Plus Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - Smaragd Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
IPC - Terra Designbelag 100% PVC frei	D 3313+D 3318+D 3360+MS 552	Ke 68; KE 60;		Power-Tak 300
IPC - Topas XXL Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong
Riviera Maison Designbelag	D 3313+D 3318+D 3360+MS 552	KE 66; KE 68; KR 430		Power-Tak 300+Multi-Strong+Ultra Strong+Supra Strong

Achten Sie bitte auf die aktuelle Klebe- und Aufbauempfehlung der jeweiligen Hersteller!